

Cleveland Wheels & Brakes Table of Contents

Title	Page	Title	Page
Wheel Assembly 5.00-5 — Nose (cont'd)		Wheel Assembly 6.00-6 — Main, External (cont'd)	
• 40-77C, 40-77D, 40-77E, 40-77F	1908	• D-30260, D-30260-1, D-30580	1950
• 40-110, 40-110B, 40-115, 40-115A, 40-115B, 40-115C	1909	• D-302991-1, D-30291-2, D-30291-3, D-30291-4, D-30291-5, D-30291-6	1951
• C-30174-1, C-30480	1910	• D-30660-1, D-30660-2, D-30660-3, D-30660-4, D-30660-5	1952
• D-30500, D-30500-1	1911	• D-30660-6, D-30660-7, D-30660-8, D-30660-9, D-30660-10	1953
• C-30174-1, C-30480	1912	• 40-407, 40-414, 40-414A	1954
• D-30500, D-30500-1	1913	Wheel Assembly 8.50-6 — Main, External	
Wheel Assembly 6.00-6 — Nose		• 40-47	1955
• 38501 (40-8), 40-30A, 40-55, 40-76A, 40-76B, 40-76C, 40-113B	1914	Wheel Assembly 7.00-8 — Main, External	
• 40-56, 40-56B, 40-76D, 40-76E, 40-76F, 40-76G, 40-76H	1915	• 40-98, 40-98A, 40-98D, 40-98E, 40-98F, 40-98G, 40-98H, 40-98N, 40-98P	1956
• 40-56C	1916	• 40-111, 40-111A	1957
• 40-120A, 40-140, 40-140A, 40-140C	1917	• 40-124, 40-128, 40-128C, 40-128D, 40-128E	1958
• 40-426	1918	• 40-171	1959
• C-30179, D-30204, D-30255, D-30570, D-30585	1919	Wheel Assembly 18 x 5.5 — Main, External	
Wheel Assembly 6.00-5 — Nose		• 40-172, 40-258, 40-289, 40-290	1960
• D-30665, D-30664-1	1920	Wheel Assembly 18 x 4.4 — Main, External	
Wheel Assembly 9.00-6 — Nose		• 40-255	1961
• 40-210	1921	Wheel Assembly 6.50-10 — Main, External	
Wheel Assembly 16 X 4.4 — Nose		• 40-40A, 40-40B, 40-40C, 40-102, 40-102A, 40-130, 40-135, 40-196, 40-256	1962
• 40-260	1922	• 40-40D, 40-135A	1963
Wheel Assembly 7.00-8 — Nose		• 40-106, 40-106A, 40-132, 40-141	1964
• 40-260	1923	• 40-138A	1965
• 40-117A	1924	• 40-162, 40-195	1966
• 40-177A, 40-193	1925	• 40-166, 40-167, 40-169	1967
Wheel Assembly 18 x 4.4 — Nose		Wheel Assembly 7.50-10 — Main, External	
• 40-212	1926	• 40-101, 40-101A, 40-101D, 40-101E, 40-129, 40-134, 40-134A, 40-179, 40-179A, 40-223, 40-234	1968
Wheel Assembly 6.50-10 — Nose		Wheel Assembly 29 x 11.00-10 — Main, External	
• 40-204	1927	• 40-133, 40-139, 40-175, 40-403	1969
Wheel Assembly 5.00-5 — Main, External		Wheel Assembly 24 x 7.7 — Main, External	
• 40-12, 40-12A, 40-78, 40-78A, 40-78B, 40-78E, 40-78J, 40-151, 40-151A, 40-230	1928	• 40-107A, 40-148, 40-170, 40-170A, 40-170B, 40-198	1970
• 40-19, 40-19A	1929	Wheel Assembly 11.00-12 — Main, External	
Wheel Assembly 6.00-6 — Main, External		• 40-211, 040-21101, 40-279, 40-279A	1971
• 27-100D (40-1), 40-32	1930	Wheel Assembly 16 x 4.4 — Main, Internal	
• 3080A (40-3), 3070 (40-5)	1931	• 40-259	1972
• 3080B (40-4), 3080D (40-116), 40-131	1932	Wheel Assembly 18 x 5.5 — Main, Internal	
• 3040 (40-6), 3050 (40-7), 3050A (40-7A)	1933	• 40-240A, 40-270, 40-276	1973
• 40-21, 40-24, 40-28, 40-28D, 40-67	1934	Wheel Assembly 6.50-8 — Main, Internal	
• 40-34, 40-58	1935	• 40-181B, 40-181C	1974
• 40-37, 40-57, 40-57A, 40-61, 40-66	1936	Wheel Assembly 7.00-8 — Main, Internal	
• 40-59, 40-59A, 40-59D, 40-59E	1937	• 40-205	1975
• 40-60, 40-60A, 40-281	1938	Wheel Assembly 6.50-10 — Main, Internal	
• 40-74, 40-74A, 40-74B	1939	• 40-176, 40-203, 40-273, 40-273A	1976
• 40-75B, 40-75D, 40-75E, 40-75F, 40-75G, 40-75H, 40-75J, 40-75S, 40-75T, 40-75W	1940	Wheel Assembly 7.50-10 — Main, Internal	
• 40-79A, 40-83, 40-83A, 40-83B, 40-84, 40-84A	1941	• 40-46	1977
• 40-41, 40-86, 40-86A, 40-86B, 40-86E, 40-86F, 40-88C	1942	Wheel Assembly 22 x 8.20-10 — Main, Internal	
• 40-90, 40-90A, 40-91B, 40-90D, 40-90E, 40-90F	1943	• 40-239, 040-23901, 40-202	1978
• 40-96A, 40-96E, 40-406, 40-406A	1944	Wheel Assembly 32 x 8.8 — Main, Internal	
• 40-97A, 40-97B, 40-97C, 40-97D, 40-97E, 40-97F, 40-99	1945	• 40-127, 40-137, 40-174	1979
• 40-113, 40-113A, 40-113C, 40-113X	1946		
• 40-120, 40-120C, 40-142, 40-142A	1947		
• 40-143, 40-163	1948		
• 40-418, 40-418A	1949		